

CONTENTS

Introduction

Controls and Connectors

CD 1740 Main Frame	1740/OM/1.1
CD 1741 Dual Channel Y Amplifier	1740/OM/1.2
CX 1744 Dual Timebase	1740/OM/1.3
CX 1743 Single Timebase	1740/OM/1.4
CX 1745 Four-trace Y Amplifier	1740/OM/1.5

Installation	1740/OM/2.1
--------------	-------------

Obtaining a Trace	1740/OM/2.1
-------------------	-------------

User Calibrations	1740/OM/2.2
-------------------	-------------

Uses of the Oscilloscope	1740/OM/3.1
Y Deflection Systems	1740/OM/3.4
X Deflection Systems	1740/OM/3.8
Trace Photography	1740/OM/3.17
Z Modulation	1740/OM/3.17

Specifications

CD 1740	1740/OM/4.1
CX 1741	1740/OM/4.2
CX 1744	1740/OM/4.3
CX 1743	1740/OM/4.5
CX 1745	1740/OM/4.7

CX 3500 Probe	1740/OM/5.1
---------------	-------------

Part 2 - Technical (Servicing) Manual

The servicing manual comprises two volumes; volume 1 contains servicing information for the CD1740, CX1741 and CX1744. Volume 2 refers to the CX1743 and CX1745.

Each sub-section listed includes the circuit diagram, a descriptive text, location diagrams, calibration procedures, and fault finding information for that section of the instrument.

VOLUME 1

Introduction to Technical Manual	6.1
CD1740 Main Frame	
Introduction	7.1
1. Power Supplies	7.4
2. Calibrator, EHT and Tube circuits	7.10
3. Drive amplifiers	7.16
Parts List	7.24

CX1741 Dual-trace Y Amplifier

Introduction	8.1
1. Beam Switching	8.4
2. Y Amplifiers	8.8
3. Attenuators	8.18
Parts List	8.20

CX1744 Dual Timebase

Introduction	9.1
1. Trigger Generator	9.6
2. Timebase Generator	9.14
3. Output Amplifiers	9.20
Parts List	9.23

VOLUME 2**CX1743 Single Timebase**

Introduction	10.1
1. Trigger and Local Power Rails	10.4
2. Timebase Generator	10.8
Parts List	10.11

CX1745 Four-trace Y Amplifier

Introduction	11.1
1. Attenuators	11.4
2. Pre-amplifiers	11.8
3. Delay Line Driver	11.15
4. Beam Switch	11.19
5. Trigger Selector	11.21
Parts List	11.23